

Follow these steps to update the QuickFlash firmware image.

- Download the latest QuickFlash Bootloader Application executable from the website at [www.embeddetech.com/QuickFlash/QuickFlash Bootloader Application V3.0.7.zip](http://www.embeddetech.com/QuickFlash/QuickFlash Bootloader Application V3.0.7.zip). Unzip the executable to your desktop.
- While holding the PROGRAM button down on the Programmer, plug the USB device cable in to power the Programmer to connect it to your PC. You should see the Power LED on constant and the USB Device LED flashing. This indicates that the Programmer is now in boot mode.
- Run the Bootloader Application executable and click the “Connect” button. You should see the executable connect to the QuickFlash Programmer’s bootloader.
- Click the “Program QuickFlash” button. The QuickFlash Programmer’s firmware will then be updated.
- Unplug the Programmer’s USB cable and then plug it back in, without holding the PROGRAM button down while plugging it in. It should now run the updated QuickFlash Programmer firmware.
- Open the QuickFlash Programmer in any terminal program using the QuickFlash’s COM port and enter the “version” command to verify that the firmware version has been updated.